

Graham Audio 2018

Vejl. Utsalg SEK

LS3/5 & LS3/5A

Cherry/Oak	22.450
Rosewood	25.300
Ebony	28.100

Stands	6.650
--------	-------

SUB 3

Cherry/Black	23.450
--------------	--------

LS6

Cherry/Oak	26.000
Rosewood	28.850
Ebony	31.600

Stands	6.950
--------	-------

LS5/9

Cherry	40.950
Rosewood	45.150
Ebony	49.350

Stands	7.250
--------	-------

LS5/8

Cherry	80.400
Rosewood	87.450
Ebony	94.500

Stands	8.100
--------	-------

VOTU

Black	169.250
-------	---------